

PROTEGIN®

Cream base for the formulation of W/O creams

- Optimally balanced cream bases consisting of emulsifiers, waxes and paraffins
- Soft W/O creams with excellent skin care properties
- Creams with high heat and freeze stability

Personal Care

INCI name (CTFA name)

PROTEGIN® XN Paraffinum Liquidum (EU); Mineral Oil (US); Petrolatum; Ozokerite;

Glyceryl Oleate; Lanolin Alcohol

PROTEGIN® W / PROTEGIN® WX Petrolatum; Ozokerite; Hydrogenated Castor Oil; Glyceryl

Isostearate; Polyglyceryl-3 Oleate

Physical and chemical properties (not part of specifications)	PROTEGIN* XN	PROTEGIN* W	PROTEGIN* WX
Form	waxy	waxy	waxy
HLB value	approx. 3	approx. 3	approx. 3

Application

- The PROTEGIN® products, so-called absorption bases, are the result of long-term research and development work.
- Using the PROTEGIN® products, the preparation of creams with a high storage stability withstanding cold and heat is possible without any problems.
- The basic substances emulsifiers, waxes and mineral oils are optimally adjusted with regard to their physical and chemical properties and their proportional quantities.
- PROTEGIN® emulsions represent the traditional type of W/O creams. They have excellent skin care properties.
- In comparison to O/W creams they are slightly more difficult to rub and are absorbed more slowly by the skin.
- PROTEGIN® XN forms solid creams, PROTEGIN® W and PROTEGIN® WX soft creams. The X types have higher emulsifying activity. Cosmetic oils can be incorporated in emulsions based on PROTEGIN® XN in amounts of up to 5 %, in creams based on PROTEGIN® WX in amounts of up to 7 %.
- For optimal stability PROTEGIN® creams should contain roughly one third of the oil phase and two thirds of the water phase.
- Electrolytes, in particular magnesium sulphate heptahydrate (approx. 0.5 %), and 3.0 to 5.0 % glycerol or other polyols act as emulsion stabilizers.
- If vegetable or animal oils or fats are used, a suitable antioxidant agent should be added.

Preparation

Heat oil phase and water phase separately to 75 – 80°C, (if PROTEGIN° W types are used to 80 – 85 °C).

Add the water phase slowly to the oil phase stirring thoroughly, cool to 30 - 25 °C while stirring and homogenize using a colloid or roller mill.

If using modern combined machines which are equipped with planetary stirrers, scrapers and Rotor–Stator apparatus switch on the homogenizer 2 or 3 times for several minutes during cooling. Machines where filling can be combined with forced passage are preferred.

Add perfume and other temperature sensitive substances at 45 – 40 °C.

Water insoluble ingredients may be added to the emulsion before homogenization.

These ingredients must be finally dispersed.

Storage/Handling

PROTEGIN® types tend to crystallization after storage time. This is reversible and has no negative influence on the quality. Short heating (85 °C) and stirring will provide adequate homogenization.

Recommended usage concentration

PROTEGIN® XN	25 - 30 %
PROTEGIN® W	28 - 30 %
PROTEGIN® WX	25 - 28 %

Packaging

600 kg pallet (30 x 20 kg box)

Hazardous goods classification

Information concerning

- classification and labelling according to regulations for transport and for dangerous substances
- · protective measures for storage and handling
- measures in case of accidents and fires
- toxicity and ecological effects

is given in our material safety data sheets.

Guide Line Formulations

W/O Soft Cream	
Phase A	
PROTEGIN® WX	28.0 %
Perhydrosqualene	4.0 %
Phase B	
Glycerin	5,0 %
Magnesiumsulfate Heptahydrate	0.5 %
Water	62.5 %
Perfume, Preservative	q. s.

W/O Cream F 27/05-1	
Phase A	
PROTEGIN® XN	26.0 %
Mineral Oil (30 mPas)	4.0 %
Phase B	
Magnesiumsulfate Heptahydrate	1.0 %
Glycerin	5.0 %
Water	64.0 %
Perfume, Preservative	q. s.

W/O Cream with Jojoba Oil		
Phase A		
PROTEGIN® WX	25.0 %	
Jojoba (Buxus Chinensis) Oil	5.0 %	
Phase B		
Glycerin	5.0 %	
Magnesiumsulfate Heptahydrate	0.5 %	
Water	64.5 %	
Perfume, Preservative	q. s.	

L 03/09

This information and all further technical advice is based on our present know-ledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments.

The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

(Status: April, 2008)

Evonik Industries AG Goldschmidtstraße 100 45127 Essen, Germany P.O. BOX 45116 Essen PHONE +49 201 173-2854 FAX +49 201 173-1828 personal-care@evonik.com www.evonik.com/personal-care

